

n - počet DT

6 2 3 1(Z) ~ 7 A 4₃


7+n-2
(8+n-2)

7+n-1
(8+n-1)

7+n
(8+n)


10+n

10+n





DT2

DT - domácí telefon
4 FP 210 52, 37
4 FP 211 02, 22



DT1



ZT - zvonkové tlačítko
4 FK 461 02



BZ - bytový zvoněk
4FN 605 11,13,17,19,29

přídavný zvoněk k DT (na svorky 3 a 4)
4FN 605 22,26



spojovací uzel



Síťový zdroj
4 FP 672 56
(4 FP 672 41)



EZ - elektr. zámek
4 FN 877 01, 02, 03
4 FN 877 11,12,13,14



"Vedlejší vchod"

Tlačídkové tablo
TT - KARAT



"Hlavní vchod"