

n - počet DT

6 2 3 1(Z) ~ 7 A 4<sub>3</sub>


7+n-2  
(8+n-2)

7+n-1  
(8+n-1)

7+n  
(8+n)


10+n

10+n




DT2


DT - domácí telefon  
4 FP 210 52, 37  
4 FP 211 02, 22



DT1



spojovací uzel



ZT - zvonkové tlačítko  
4 FK 461 02

BZ - bytový zvoněk  
4FN 605 11,13,17,19,29




přídavný zvoněk k DT (na svorky 3 a 4)  
4FN 605 22,26



SN

Síťový zdroj  
4 FP 672 56  
(4 FP 672 41)

230V / 50Hz




"Vedlejší vchod"

Tlačídkové tablo  
TT - KARAT



EZ - elektr. zámek  
4 FN 877 01, 02, 03  
4 FN 877 11,12,13,14



"Hlavní vchod"