




DT2

DT - domácí telefon
 4 FP 210 52, 37
 4 FP 211 02, 22
 a se zábranou odposlechu
 4 FP 210 38, 110 73




DT1



EV a TT GUARD
 EV a TT 94
 (TT 85)


Elektrický zámek EZ
 4 FN 877 01,02,03
 4 FN 877 11,12,13,14



Síťový zdroj
 4 FP 672 55
 (4 FP 672 39,40)
 [4FP 672 18]

230V/50Hz

n = počet DT



ZT - zvonkové tlačítko
 4 FK 461 02

BZ - bytový zvonek
 4FN 605 11,13,17,19,29

přídavný zvonek k DT (na svorky 3 a 4)
 4FN 605 22,26



u () a [] chybí
 oba na svorku -