



DT2

DT - domácí telefon  
4 FP 210 52, 37, 211 02  
a se zábranou odposlechu  
4 FP 210 38, 110 73







DT1



ZT - zvonkové tlačítko  
4 FK 461 02


BZ - bytový zvoněk  
4 FN 605 11,13  
17,19



"Vedlejší vchod"



EZ - elektr. zámek  
4 FN 877 01, 02, 03  
4 FN 877 11,12,13,14



"Hlavní vchod"

Tlačidlové tablo  
TT - KARAT